


Lastname: _____

5Digit SS: _____

LABORATORY**Intellectual****Property**

LAB 8: Design with Intellectual Property Cores

(10 points)

In this lab, you will be introduced to IP design for FIR filters and FFTs. In many projects time-to-market constraints require the use of predefined block, so called IP block. IPs may be available as HDL source (soft core), parameterized core (firm core), or hard cores (fixed netlist core). FPGA vendor like Altera or Xilinx provide some basic DSP blocks like, IEEE floating-point operations, NCO, FIR, FFT within a basic subscription of their software tool. More complex blocks such as PCI core, DCT, or MPEG and JPEG coder cost extra.

In the **pre-lab**, you will use “pencil-and-paper” to compute the results you expect later in your design implementation. In the **design part**, you will implement a F5 half-band filter using PDA and a 256 point FFT. This lab does not use the DE2 boards.

Lab Objectives

After completing this lab you should be able to

- Configure, generate and simulate a FIR filter use a FIR Compiler core generator
 - Configure, generate and simulate a 256 point FFT use a FFT MegaCore Function
 - Apply filtering to different noise types
-

Pre-lab (3 points)


1. A key point when using an IP core is to understand the functionality of the I/O ports and possible design choices. This data can be found in the “User Guide” of the core and are posted on the class webpage. Using the user guide give a brief description of the I/O ports. For control signal specify if input/output, active low/high and synchronous/asynchronous.

Signal	Direction	Brief Description
clk	Input	Positive edge trigger clock for the registers
reset_n		
ast_sink_data		
ast_sink_valid		
ast_source_ready		
ast_sink_error		
ast_source_data		
ast_sink_ready		
ast_source_valid		
ast_source_error		

Lastname: _____

LABORATORY**Intellectual****Property**

5Digit SS: _____



2. The FFT core used a block-floating-point format for the data, i.e., all integers are assigned ONE power-of-two exponent 2^{-b} . For instance 720 with exponent -3 is represented as: $720=90/2^{-3}$
For the exponent -3 complete the following table

Integer	BFP representation
	$100 / 2^{-3}$
80	$1 / 2^{-3}$
736	

3. For the 256 point FFT testbench the following input data are used: $x(1) = 20$; $x(2) = 40$; $x(3) = 60$; $x(4) = 80$, $x(5) = 100$; $x(6) = 120$; $x(7) = 140$; $x(8) = 160$, and $x(9\dots 256) = 0$ for all others. Using MatLab determine the first and last two FFT values of $X=fft(x)$ rounded to the nearest integer:

X(1)	X(2)	X(255)	X(256)

4. From the FFT "User Guide" manual of the core give a brief description of the I/O ports. For control signal specify if input/output, active low/high and synchronous/asynchronous.

Signal	Direction	Brief Description
clk	Input	Positive edge trigger clock for the registers
reset_n		
inverse		
sink_valid		
sink_sop		
sink_eop		
sink_real		
sink_imag		
sink_error		
source_ready		
sink_ready		
source_error		
source_sop		
source_eop		
source_valid		
source_exp		
source_real		
source_imag		


Lastname: _____

5Digit SS: _____

LABORATORY

Intellectual

Property



VHDL Design-lab

Follow the directions below to implement a parallel DA filter design for the F5 filter and a 256 point FFT.

A. Getting Started

If you are in B114 or the digital logic lab:

1. On the desktop double click on **Engineering folder** and start version 9.1 of **Quartus II**. Do not use Quartus version 10 since it does not has a build-in simulator.
2. You should not save anything on the local hard disk. You will have to use a USB flash drive, or your “mapped” home directory to save the files. Create (if not done in a previous lab) a new folder named **DSPwFPGAs** on your mapped network drive.


B. Configure FIR Compiler for F5

1. Within your **DSPwFPGAs** folder make a new folder called **DE2_lab8**. Download the file "f5.dat" from the class webpage and put the file in your **DE2_lab8** folder. Create a project f5 and as device select **EP2C35F672C6**.
2. Start the from **Tools->MegaWizard Plug-In Manager**. From the **Installed Plug-Ins** select **DSP->Filter->FIR Compiler v9.1** and use f5 as output file name. The **FIR Compiler v9.1 IP Toolbench** should open.
3. Select **Step: Parameterize** and the Window similar to Fig. 1 below opens. Click on **Edit Coefficient Set** and a window called **Coefficients Generator Dialog** opens. Then select **Imported Coefficient Set** and Browse to the **File** you downloaded from the course webpage: f5.dat then click **Ok**.
4. Back in the **Parameterize Window** click on **Time Response & Coefficient Values** tab and you should see the length-11 impulse response as shown in the Figure 1 below. Use **Input Bit Width** 16 and the output **Full Resolution** should be 26. For **Coefficients Scaling** select **None**. The Device should be set already to Cyclone II if you have set up the project correctly.
5. The FIR Compiler let you choose between different architecture and resource types and provides approximations on the used LEs and multipliers. For **Data** and **Coefficient Storage** select **Logic Cells**. Complete the following table by selecting the **Structure** and **Multiplier Implementation** if applicable.


Lastname: _____

LABORATORY
Intellectual
Property

5Digit SS: _____



Structure	Multiplier Implementation	Logic Cells	Multipliers
Fully Parallel Filter	N/A		
Variable/Fixed Coefficient:	Logic Cells		
Variable/Fixed Coefficient:	DSP blocks		

**Figure 1:** f5.dat FIR compiler parameters.

Lastname: _____

LABORATORY

Intellectual

Property

5Digit SS: _____

**C. Generate F5 PDA VHDL, Compile and Simulate**

After the FIR compiler is configured we now generate the netlist, compile and simulate the filter.

1. Select **Structure->Distributed Arithmetic: Fully Parallel Filter** and press then **Finish**.
2. Now click on **Step 3: Generate** of the **IP Toolbench**. A window open and shows a brief description of the generated files and the I/O ports of the FIR core.
3. Perform a Functional Simulation of the design **f5.vhd** with the impulse response and try to match with the **f5** simulation shown in Figure 2. The following **input** port needs to be specified: **clk, reset_n, ast_sink_data, ast_sink_valid, ast_source_ready, ast_sink_error**. Remember that **reset_n** is active low and “sink” are input signals and “source” are output signals! All filter coefficients should be seen in the output signal **ast_source_data**. Add your e-signature and print this simulation in landscape format.




Figure 2: f5.vhd PDA core simulation.

4. Now run a full compilation. From the **Compilation Report** and the **Classic Timing Analyzer Tool (Processing menu)** for **clk** determine

Total logic elements = _____

Embedded Multiplier 9-bit elements = _____

Total memory bits = _____

Registered Performance = _____ MHz

Enter these resource and performance data also in your f5.vhd header file.

5. Compare this design with the estimation given by the Parameterize ToolBench under B.5 and compute the error

Lastname: _____

5Digit SS: _____

**LABORATORY
Intellectual
Property**



Total logic elements estimation error = _____ (LEs)

Estimation error in Percent = _____ %

D. Configure FFT MegaCore Function for length 256 FFT

In the second part of the lab we now will use the FFT core generator to build a length-256 FFT.

1. Within your folder called `DE2_lab8` create a project `fft` and as device select `EP2C35F672C6`.
2. Start the **Tools->MegaWizard Plug-In Manager**. From the Installed Plug-Ins select **DSP->Transfroms->FFT v9.1** and use `fft` as output VHDL file name. The **FFT Megacore Toolbench** should open.
3. Select **Step 1: Parameterize** and a window opens. Click on the **Architecture** tab and select **I/O Data Flow Streaming**. Then click on the **Implementation Options** tab and set **Implement Multipliers in: DSP Blocks/Logic Cells**. With **Structure** you can choose how the complex multiplier is implemented: 4 Mults/2 Adders or with 3 Mults/5 Adders. Select the default 4 Mults/2Adders configuration. Now click on the **Parameters** tab and set FFT parameter: **Transform Length=256; Data Precision=16; Twiddle Precision=16**. Complete the data for the resource estimation:

LEs = _____

M4K RAM Blocks = _____

DSP Block 9-bit elements = _____

Transform Calculation Cycles = _____

Block Throughput Cycles = _____

4. The Cyclone C35 device on the DE2 has limited resources, i.e., 35K LEs; 105 M4Ks, and 70 DSP 9-bit blocks. Determine with the **Resource Estimation** what the maximum FFT transform length is such that it can be build with C35 resources. Determine also which resource the limiting factor is by modifying the **Transform Length**.

Maximum length FFT with C35 device: _____

Resource limit (cycle one) : **LEs** **M4Ks** **DSP block 9-bit**

E. Generate Length 256 FFT VHDL, Compile and Simulate


In the pre-lab we became familiar with the block-floating point format and we developed testbench data for the length-256 FFT we now will use.

1. Select again **Transform Length = 256 points** and 16 bit precision, 4 Mults /2Adders and **Streaming Architecture** in case you had changed it then press **Finish**.

Lastname: _____

LABORATORY
Intellectual
Property

5Digit SS: _____



2. Next click on **Step 3: Generate** of the **IP Toolbench**. A window opens and shows a brief description of the generated files and the I/O ports of the FFT MegaCore.
3. Perform a **Functional Simulation** of the design `fft.vhd` with the testbench data from the prelab, i.e., $x=20:20:160$ as in Figure 3. The following **input** ports need to be specified: `clk`, `reset_n`, `inverse`, `sink_valid`, `sink_sop`, `sink_eop`, `sink_real`, `sink_imag`, `sink_error`, `source_ready`. Remember that `reset_n` is active low and `sink_sop` is needed to be high one clock cycle when the sequence starts and `sink_eop` is high one clock cycle when the sequence ends. Make sure the input sequence is exact 256 cycles long. Use a `clock = 10ns` for easy counting clock cycles. The output data start at 5.3 μ s and the end is at 7.8 μ s.




Figure 3: FFT **input** data specification (a) Start Of (data) Package (b) End Of (data) Package.

4. Using a 10 ns clock period the output data are available at 5.3 μ s (see active `source_sop`) and the end is at 7.8 μ s (see active `source_eop`). Verify this data with your test data from the prelab. Exponent of the data should be -3. Add your e-signature and print all 4 simulations in landscape format.

Lastname: _____

LABORATORY
Intellectual
Property

5Digit SS: _____





Figure 4: FFT output data specification (a) Start Of (data) Package (b) End Of (data) Package.

5. Now run a full compilation. From the **Compilation Report** and the **Classic Timing Analyzer Tool (Processing** menu) for `clk` determine

Total logic elements = _____

Embedded Multiplier 9-bit elements = _____

Total memory bits = _____

Registered Performance = _____ MHz

6. Compare this design with the estimation given by the Parameterize ToolBench under D.3 and compute the error

Total logic elements estimation error = _____ (LEs)

Logic elements Estimation error in Percent = _____ %

F. Deliverables:

1. Solve the problems of the pre-lab. (3 points).
2. Complete this report, print the Quartus simulations for f5 (see Fig. 2) and 4 simulations for the length-256 FFTs (see Fig. 3 and 4) including e-signature. (7 points).

Make sure your name and SS is on all pages you turn in!